


CARTRIDGE SHOULD BE KEPT AT 70° F+ FOR BEST RESULTS


### INSTRUCTIONS FOR USING CARTRIDGE UNIT

**1**

SHAKE WELL  
BEFORE USE




Unscrew Locking  
Nut and  
Remove D Caps




**2**

Place Static Mixer  
Over Cartridge  
Neck and Secure  
Tightly with  
Locking Nut





**3**

Pull Back  
Pistons in Gun  
and Securely  
Load Cartridge  
in Cradle



**4**


Hold Gun  
Straight Up at  
a 90° Angle  
and Slowly  
Pull Trigger to  
Purge Air from  
Unit. Drive  
Material to  
Top of Mixer.



**5**


Tilt Gun  
Down and  
Squeeze First  
2-3 Shots of  
Material into  
A Disposable  
Cup, Etc.

Gun Should Be  
Tilted Down  
Whenever  
Dispensing or  
When Cartridge  
is Being Used.



**6**

To Re-use Cartridge, Tilt  
Cartridge Unit Down,  
Remove Mixer,  
Wipe Excess  
Material Off  
Cartridge Neck,  
Then Replace  
D-Caps and  
Screw on  
Lock Nut.  
Use New  
Mixer  
with  
Next  
Application.




**DEFECT PREPARATION IS CRITICAL!**

Spal-Pro 2000 can be used to permanently repair a variety of common floor defects, but proper defect preparation is critical in ensuring that your repair will last. There are two important factors in repairing any floor defect:

REPAIR AREA MUST BE DRY AND COMPLETELY CLEAN  
OUTSIDE OF REPAIR AREA SHOULD HAVE A VERTICAL EDGE...  
DO NOT FEATHEREDGE REPAIRS!

Edges of repair can be defined using a concrete saw or right angle grinder with a diamond/abrasive blade. A cold chisel is also acceptable. Vertical edge of repair area should be 1/2" minimum or 3/4"+ (preferred). Any concrete that is not structurally sound should be removed along with any debris, dirt, oils, etc.




**Spalled Joints**


or

THESE ARE ABBREVIATED REPAIR INSTRUCTIONS. FOR MORE DETAILED REPAIR SPECIFICATIONS REQUEST OUR BASIC GUIDE TO FLOOR REPAIRS by calling 800-223-6680 or download at [www.metzgermcguire.com](http://www.metzgermcguire.com).

**Random Cracks**



**Gouges, Holes**




**INSTRUCTIONS FOR FILLING FLOOR DEFECTS**

**1 Defects Less than 2" Wide**

For Narrower Joints, Cracks, Popouts, etc., Prepare Area as Outlined in Defect Preparation and Slightly Overfill Defect With Material.

**2**

Allow Material to Cure into a Solid and Razor off Flush with Floor Surface Using Tile Scraper with Disposable Blade.



**1 Defects 2" or Wider**

For Wider Joints, Cracks, Pot Holes, Etc., Prepare Area as Outlined in Defect Preparation. Efforts Should Be Made to Fill Defect Flush as Shaving is Very Difficult for Wide Areas. If Material is Overfilled Slightly, It Can Be Sanded Down Using a Sanding Block or Sander at Low Speed.

Joints and Cracks Should Be Monitored To Ensure Material Does Not Sink and Leave a Concave Profile. Apply Additional Material if Necessary.

